



5°-45° Angle



Sturdy &amp; Reliable



Widely Compatible



MC24

User Manual

## INTRODUCTION

This Unimount is the perfect addition to any desk or place where you work. It has multiple rubber guards to make sure nothing slips and stays sturdy. With a low center of gravity, it can withstand the weight for any device. The holding tray allow you to keep other things close by without the thought of losing them

## PACKAGE CONTENTS

- |                |   |
|----------------|---|
| 1x Phone Mount | 1x Allen Key and Screw                    |
| 1x Bottom Tray | 1x Paper with 5 different rubber stickers |
| 1x Black pole  |   |

## HOW TO USE


- 1) Unbox everything and make sure you have all pieces
- 2) Take the rubber pieces off the pad and start to stick them in their designated spots
- 3) Connect the pole to the mount and then to the base
- 4) Make sure all pieces fit snug
- 5) Shove the screw up the black pole
- 6) Use your allen key to twist the screw tight
- 7) Make sure everything is tight and secure so your device doesn't fall and break. Enjoy!

1

## PRODUCT OVERVIEW



Holding Tray



4.5" Height



45° Angle

## SPECIFICATIONS & FEATURES

- Stand is approx 15.5cm h and the base has a 9.5cm D
- Universal Mount to hold 4-13 inch devices
- Considerate design using gravity and rubber grips
- Large tray at bottom for storage
- Can tilt at a 45 degree angle

2

## CARE AND SAFETY

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.

3